




1

Hold headset before fitting

Hold the headset with your thumb and first two fingers and the Soft Spring pointing upward and the speaker outlet pointing toward your ear.



2

Compress foam tip

Roll and compress the tip into a thin round cylinder with as small as possible diameter. The cylinder should be free from wrinkles.




3

5 seconds

Place headset in ear within 5 sec.

Insert the headset fully into your ear, while twisting the headset backwards.



4

5 seconds

Push headset fully into ear

Pull your ear back with your other hand and push the headset further into the ear canal. The BCM must be in contact with the ear canal and not be visible once inserted.



5

20 seconds

Hold headset in ear for 20 seconds

Hold headset in your ear for 20 seconds until the foam has fully expanded.



6

Place Soft Spring in ear

Use your index finger to push the Soft Spring into the upper bend of your ear to ensure a secure headset fit and consistent pressure on the BCM.



7

Place Cable Retainer behind ear

Place the Cable Retainer behind your ear to ensure the cable is held comfortably and securely over the ear.



8

Test headset on radio

Test your voice quality by transmitting to another radio. If transmission signal is low or the headset is sitting loose, refit the headset and/or try another foam tip size.